


# **CABINET PARTS**

Illus. No.	Part No.	DESCRIPTION
1		Cabinet (Not A
•		Serviceable Part)
2	2157591	Hinge (Top)
3	2166108	Roller-Front (2)
4	489426	Screw
5	489385	Clamp, Tube (Water Supply Line)
6	489457	Screw
12	549193	Clamp-Cord
13	937360	Cord-Service
15	489423	Screw
16	2163758	Hinge, Center
17	2163757	Shim, Hinge
18	400412	Center Screw
20	489413 2179829	Hinge Butt
23	2172745	Shim, Bottom
		Hinge
24		Fitting, Water Tube (NOT SERVICED)
27		(NOT SERVICED)
27	2151652	Hole Plug (6) White
	2151653	Almond
	2151654	Gold
31	2166251	Cover, Valve
35		Corner Filler (2)
	2163733	White
	2166187	Almond
26	2166188	Gold
36	2163889	Grille White
	2166133	Almond
	2166134	Black
38	487576	Washer
39	1123517	Shim
40		Cover-Hinge
	2160403	White
	2160404	Almond
41	2160405	Gold Rail, Center
41		(NOT SERVICED)
42		Corner Filler,
		Grille
	2166156	White
	2166204	Almond
40	2166205	Black
43 44	2166160 2179786	Pin, Hinge
44	21/9/00	Cover, Unit

## **DOOR PARTS**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **DOOR PARTS**

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
110.	NO.	DESCRIPTION	<u> 140.</u>	NO.	DESCRIPTION	<del>- 100.</del>	NO.	DESCRIPTION
1		Refrigerator Door	9		Door Gasket,		2171140	Trim, Door Shelf
		Panel			Magnetic		2159367	Bracket, Door Stop
	2171269	White		2159057	Mist Beige	27	488921	Screw
	2171270	Almond	10	991259	Tape	28		Hole Plug
	2175871	Gold	12		Cover, Screw		844478	White
2		End Cap		9791769	White		989196	Almond
	9791773	White		9791770	Almond		989893	Gold
	9791774	Almond		981182	Chrome	29	2156007	Plug-Trim (4)
	1101632	Chrome	13		Nameplate		2156006	Plug-Trim (4)
3		Hole Plug (2)		2162781	White Model	31	2170950	Compartment Door
	534927	White		2162782	Almond Model	33		Handle, F.C.
	989197	Almond		2152334	Gold Model		2171043	White
	989879	Gold	16	2171040	Trim, Door Shelf		2171044	Almond
4		End Cap, Handle (2)	17	489028	Screw		2175873	Cherry Hill
	9791771	White	18	2171142	Trim, Door	36		Bracket, Door Stop
	9791772	Almond	19		Freezer Door		2159368	White And
	2148503	Chrome			Panel			Almond Models
5		Handle Center		2159270	White		2159364	Gold Model
	2148035	White		2159271	Almond		2171144	Trim–Door (2)
	2148036	Almond		2175872	Gold	38	943187	Shim
	1106189	Cherry Hill	20		Hole Plug	39		Handle End
6	489006	Screw		1122653	White		9791776	White
7	943188	Spacer		1122654	Almond		9791777	Almond
8	487909	Screw		1122694	Gold		943184	Chrome
			23		Door Gasket,	41	2156003	Endcap (4)
					Magnetic	42	2171141	Trim, Door
				2159327	Mist Beige			

#### **LINER PARTS**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

## **LINER PARTS**

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2 3	531933 2166181	Grommet (2) Gasket, Evaporator Cover (Side)
4 5	2176340 549512	Timer, Defrost Thermostat Tube Barrier
6 7	941839 2172542	Hole Plug Wire Assy. Control Box
8 9 10 11 12 13		Socket, Light (2) Damper, Air Fan Motor Fan Blade Control Box Thermostat Assembly (Includes Items 5, 18, & 36)
14 15 16 17 18 19	489438 489412 2163818 946059 2163802 1108112	Screw Screw Cover–Evaporator Light Bulb (2) Weight, Thermal Rocker Arm
20 21	2163809 2176281	Switch Post, Damper Cover, Air Diffuser
22 23 24	2176296 2172575 2176280	Knob, Thermostat Air Tower Air Diffuser, Bottom
25 26 27 28 29	2172679 2172563 944759 1103725 2163827	Freezer Floor Air Diffuser, Top Cover, Hole Hole Plug Bracket, Fan Motor
30	2166178	Gasket, Evaporator Cover (Top)
31	2174629	Air Return & Foil Assembly
32 33	487996 2174610	Cap Wire Assembly, Freezer Compartment
34 35	2176297 2163810	Knob, Damper Bracket,
36	2172532	Damper Knob Seal, Rear Thermostat
37	2172594	Gasket, Air Diffuser
38	2176341	Clip, Defrost Timer

## **UNIT PARTS**



## **UNIT PARTS**

Illus.				Part		Illus.		
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	2174620	Plate, Unit Mounting	28	2169441	Compressor (Includes Items			arts Not Illustrated
2	489242	Screw			12, 13, 15, 29,	and C	ptional	Parts Not Included
3	2172670	Condenser			32, 38 & 56)			
4	2176300	Heater, Defrost			(Also Order		978025	Valve, Access
5	2176337	Evaporator Assy.			482801		.=	(1/4")
6	489414	Screw			Installation Kit		978026	Valve, Access
7	2172619	Drain Pan			& 876765		070007	(5/16")
8	2172694	Defrost Bi-Metal		0404400	Tube Kit)		978027	Valve, Access
9	2176301	•	-	2164409	Drier		070000	(3/8")
10	2163780	Extension, Air		2155774	Clamp		978028	Valve, Access
40	0400050	Baffle	32	2169137	Capacitor		978029	(1/2") Valve, Access
12	2162358	Cover	38	1127675	(Service Only) Wire Assembly		910029	(5/8")
13	2154759	Overload	39	2172697	Air Baffle		978030	Valve, Access
14		(Includes Relay) Grommet (4)	40	2166191	Motor, Condenser		310030	(3/4")
14	2174621	Production	42	2176279	Wire Assy. Unit		876764	Valve, Access
	1100826	Service	43	851732	Fan Blade		010104	(3/16")
15	1100020	Relay	44	486692	Nut		482278	Start Kit
13		(See Overload)		2172660	Tube, Discharge		102210	otar rut
17	2163782	Roller (2)	47	2172662	Tube, Suction			
18	981126	Rivet	1	2154109	Tube, Process	REF	RIGERA	NT CHARGE
19	2166244	Clip, Heater	49	2174670	Tube, Condenser			
21		Nut			To Heat Loop			4.0 Ozs.
		(Not Serviced)	56	487240	Screw			(R134A)
		(	58	2163795	Evap. Tray			



#### **SHELF PARTS**

For Models: ET18NKXDW01, ET18NKXDN01, ET18NKXDG01 (White) (Almond) (Gold) **FREEZER** Illus. Part No. No. **DESCRIPTION** 8 Ice Tray (2) Shelf (2) Cover, Crisper 841180 2 2166147 2174664 3 2170954 Crisper Pan Support, Crisper REFRIGERATOR 6 2172541 Cover Track, Crisper Shelf 2163835 8 2176275 9 2170955 Crisper Pan Insert 10 2166149 14 2170956 Meat Pan 15 2163848 Cover, Meat Pan 2 10 14 6

IIIus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and		Cust	Customer Touch-Up Material			LITERATURE PARTS		
Optional Parts (Not Included)			*350942	Primer, White	LIT	2172667	Service &	
Misc	ellaneo	us -		*350939 *350930	(13 Oz. Spray Can) Enamel, Black (13 Oz. Spray Can) Enamel, White	LIT	2172665 2175930	Wiring Sheet Energy Label Use & Care Guide
	978941	Insulation, Fiberglass (63–1/2" x 35–1/2" x 2–5/8")		*350956 72017	(13 Oz. Spray Can) Enamel, Almond (13 Oz. Spray Can) Brush Touch-Up Kit	l ——	wing May	y Be Purchased JRSELF
	212643	Sealer, Gum (4 Feet)		72032	(White) Brush Touch-Up Kit	RE	PAIR MA	NUALS
	479502	Tape, Vinyl (3/4" x 108")		72107	(Black)	Lľ	T677969	Do-It-Yourself Manual Ref./Fzr.
	876305	Kit, Insulation (14 Pcs.		72107	Brush Touch-Up Kit (Almond)	Lľ	T677971	Do-It-Yourself Manual, Icemaker
	876370	3" x 24" x 48") Kit, Insulation	Refi	inishing	<u>Materi</u> al			
		(2 Pcs. 3" x 24 " x 48")		799344	Enamel, White (1 Qt. Uncut)		MAKER D INST	<u>ALLAB</u> LE
	876029	Kit, Foam Slab (30" x 32–1/2" x		978883	Enamel, Almond (1 Qt. Uncut)			ECKMF94
	505587	1–1/2") Sealer, Mastic (1 Qt.)		833938	Kit, Terminal Connector	TOR	X SCRE	W WRENCH
	511873	Touch-Up, White Porcelain (2 Oz.)					1117510	Torx Key
	542638	Grease, Silicone (1/2 Oz.)						
	542639	Cement, Alumilastic (1–1/4 Oz.)	To	Be Used \	e Spray Paint Is Not Where The Paint			
	606755	Bag, Insulation (36–5/8" x 46")		y Make Co or Gaskets	ontact With The			
	799833	Kit, Evaporator Repair (Aluminum Epoxy)						
	799832	Kit, Porcelain Repair (White)						
	503695	Cork Sealer (1/4 Pound)						
	2172516	Door Reversal Instructions						